



EA9 handi-lift

the lift for straight stairs

lifts that make a change

HANDI-LIFT TYPE EA9

The Handi-lift is designed for straight staircases and is built individually with regards to the width and length of the staircase. Normally the lift can be installed without considerable rebuilding costs.

The lift can be delivered in both an indoor and outdoor version, installed on either wall or columns. The Handi-lift is provided with barrier arms and sensitive flaps on and pleasent drive. the front and rear edge of the platform. The barrier arms, flaps and platform are folded electrically,

hereby the lift takes up minimal space on the stair when "parked". In parked position the barrier arms will be folded down behind the platform and is thus protected against vandalism. The Han-di-lift is built in accordance with the latest European standards and is delivered CE-marked. The lift is equipped with Soft start and brake, which ensures a smooth

The Handi-lift can be delivered with batteries, which ensures operation during power cuts.



Specifications

Load:	225 kg / 30
Travel:	From 4 to 4
Speed:	0,11 m / s
Driving	750 w 3 ph
Platform motor:	24 v
Barrier-arm motor:	24 V
Elelctric supply:	1 phase 230
Driving mechanism:	Rack with a
Construction:	Steel-and a
	wall or on a

)0 kg / 325 kg 45 degrees slope 0 V, 10 A overspeed governor aluminium rails on the wall or <u>on columns.</u>

The lift is reversible so it can be built to the right or left side, which gives it a higher recycling value.

Dimensions

Rail width: Width folded up: Width folded out: Platform standard size: 1000 x 800 mm Platform height: Other platform sizes:

70 mm 300 mm 1050 mm 45 mm 1000 x 750 mm 1000 x 700 mm 1200 x 800 mm 1300 x 800

Safety details

Overspeed governor and brake Limit switch Weight sensor Manual emergency raising of barrier arms and platform Manual release mechanism Pressure sensitive surfaces that stops the lift when it runs into an obstacle.



- customized for your home









HANDI-LIFT TYPE EA9 H/S

Handi-lift EA9 raise/lower is a further development of the Handi-lift EA9, which is ideal when the space at the end of the stair case is minimal.

The lift can be parked close to the bottom step.

The drive is begun with a vertical raise until the lift is free from the stairs. It then drives its course and is then lowered vertically once it has reached the top of the stairs.

> The raise/lower lift can be delivered with the same equipment as the traditional lift.

- Handle for standing persons
- Possibility for handrail on top of rail
- Optional colour (RAL code)
- Front and rear access
- Option of folding seat
- Rail for wall
- Rail for columns







